



Sanitizing Displays and Contact Surfaces on Dispensing Equipment*

For sanitizing displays and contact surfaces like handles and switches, use commercially available sanitizing wipes with bleach (like Clorox wipes) or bleach cleaning sprays with < 10% bleach.

- If using a spray, do not spray directly on equipment. Spray sanitizer onto clean microfiber cloth, then wipe surfaces. This will prevent unwanted scratches.

Do not mix bleach and alcohol!

Do not use:

- Lysol Wipes
- Quat-based cleaners (Quaternary Ammonium Compounds)
- Ammonium chloride-based cleaners
- Hydrogen Peroxide

These contain chemicals which may cause damage.

**Manufacturers of cleaning and sanitizing products sometimes change their formulas without notification. Compatibility in perpetuity cannot be presumed. These suggestions are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use are beyond our control.*

