











Setup

How to Brew Your Perfect Cup

Water	Coffee
4 Cups/20 oz	~4-5 tbsp
6 Cups/30 oz	~6-7 tbsp
8 Cups/40 oz	~8-9 tbsp
10 Cups/50 oz	~10-11 tbsp
6 Cups/30 oz	~6-7 tbsp ~8-9 tbsp

1 tablespoon per cup. Adjust for your preference

SIMPLE BREW DIRECTIONS



Fill Carafe with water - minimum 4 cups (20oz), maximum 10 cups (50oz). Open Flip Lid on top of coffeemaker; pour water into Top Tank. Close Flip Lid. Do not open lid during heating or brewing.



Position Drip Free carafe on base under Brew Funnel. Press Brew button to begin heating. (~6 minutes) Coffeemaker is on when the red light around the Brew Button is illuminated.



Once heating is complete, the digital display will read 'Brewing'. To turn the Warmer Plate off when brewing completes, push the Brew Button (no red light visible).



Warmer plate will automatically shut off after 2 hours. Press & hold Brew Button for 5 seconds to turn back on.



PROGRAMMABLE BREW START DIRECTIONS

Press the Auto-Start button. The H (hour) and M (minute) buttons will light up.



Set the time by using the H (hour) and M (minutes) buttons, take care to select correct



When your desired brewing time is on the digital display, press the Auto Start button to active and the button will illuminate white.



Heat N' Brew is now programmed to start heating at your designated time.